

Linker Instruction



Step 1: Open the lid and insert the multi row or single row hopper.



Step 2: Load the link magazines. The links only fit in one direction and need to be loaded as in the picture below.





Step 3: Insert the link magazine in the linker. The links should slide down as the magazine snaps into place. Fill the hopper with ammunition. The ammunition needs to be pointing in the same direction as in the picture.





Step 4: Crank the handle clockwise. Do not crank anti clockwise. In case of jam, open the lid. When the link magazine is empty fill it or change it for a full one.





Step 5:

The linked ammunition comes out the bottom of the linker.







